

Descaling Dishwashing Machines

BEFORE YOU START

- ✓ Read label directions and Safety Data Sheets (SDS) of chemicals prior to use.
- ✓ Wear Personal Protective Equipment as per the SDS such as safety glasses and suitable gloves when handling chemicals.
- ✓ NEVER MIX CHEMICALS.
- ✓ Turn OFF chemical dispenser.
- ✓ Empty the dishwashing machine.
- ✓ Follow all dishwashing machine manufacturer instructions.

PRE-RINSING THE MACHINE

1. Fill the dishwashing machine with clean water.
2. Run one full wash cycle.

DESCALING THE MACHINE

1. Refill the dishwashing machine and add approximately 20mL SCALE OFF for each litre of water (ie 300mL for a 15L tank).
2. Run one full wash cycle.
3. Inspect the dishwasher interior. If scale is still present scrub or scourer the areas of concern. Neat SCALE OFF can be used to help this process.
4. Run full wash cycle.
5. Inspect the dishwasher interior. Repeat step 3 until you are happy with the appearance of the machine.
6. Empty the dishwashing machine.

SETTING UP THE MACHINE FOR USE

1. Fill the dishwashing machine with clean water.
2. Run one full wash cycle.
3. Empty the dishwashing machine.
4. Ensure that no SCALE OFF is left in the dishwasher before the chemical dispenser is turned on.
5. Turn ON the chemical dispenser.
6. Refill the dishwashing machine and titrate the wash water to ensure correct dispenser set up.